OFFICE OF MOTOR CARRIERS

U. S. DEPARTMENT OF TRANSPORTATION FEDERAL MOTOR CARRIER SAFETY ADMINISTRATION

DRIVERS' PRETRIP CHECK LIST

INSIDE

[] Parking Brake (Apply)

START ENGINE

- [] Oil Pressure (Light or gauge)
- [] Air Pressure or Vacuum (Gauge)
- [] Low Air or Vacuum Warning Device (Air pressure below 40 psi check on pressure build-up. Air pressure above 60 psi deplete air until warning device works.) (Vacuum below 8 inches Hg. check on build-up. Above 8 inches Hg. deplete vacuum until device works.)
- [] Instrument Panel (Telltale lights or buzzers)
- [] Horn
- [] Windshield Wiper and Washer
- [] Heater Defroster
- [] Mirrors
- [] Steering Wheel (Excess play)
- [] Apply Trailer Brakes in EMERGENCY
- [] Turn on all Lights including 4-way Flasher
- [] Fire Extinguisher and Warning Devices

OUTSIDE

FRONT

- [] Headlights
- [] Clearance Lights
- [] Identification Lights
- [] Turn Signals and 4-way Flasher
- [] Tires and Wheels (Lugs)

LEFT SIDE

- [] Fuel Tank and Cap
- [] Sidemarker Lights
- [] Reflectors
- [] Tires and Wheels (Lugs)
- [] Cargo Tie-downs/or Doors

REAR

- [] Tail Lights
- [] Stop Lights
- [] Turn Signals and 4-way Flasher
- [] Clearance Lights
- [] Identification Lights
- [] Reflectors
- [] Tires and Wheels (Lugs)
- [] Rear End Protection (Bumper)
- [] Cargo Tie-downs/or Doors

RIGHT SIDE

- [] Fuel Tank and Cap
 -] Sidemarker Lights
-] Reflectors
- [] Tires and Wheels (Lugs)
- [] Cargo Tie-downs/or Doors

ON COMBINATIONS

- [] Hoses and Couplers
-] Electrical Connector
- Couplings (Fifth wheel, tow bar, safety chains, locking devices)

ON VEHICLES TRANSPORTING HAZARDOUS MATERIALS

- [] Marking or Placards
- [] Proper Shipping Papers

INSIDE

STOP ENGINE

- [] Release Trailer Emergency Brakes
- [] Apply Service Brakes–Air loss should not exceed
 - 3 psi per minute on single vehicles
 - 4 psi per minute on combinations

FASTEN SEAT BELT

DRIVER'S NAME:

DATE: _

TRACTOR / TRAILER UNIT NO.S: _

